

# **Quick Start Guide for ETSI Adaptivity and Carrier Sensing Test ver. 1.0.0**

## **Contents**

<b>Release History .....</b>	<b>2</b>
<b>1. Introduction .....</b>	<b>3</b>
<b>2. Driver configuration .....</b>	<b>3</b>
<b>3. Driver configuration – disable (default setting) .....</b>	<b>3</b>
<b>4. Driver configuration – enable for ETSI Adaptivity test .....</b>	<b>4</b>
<b>5. Driver configuration – enable for Carrier Sense test .....</b>	<b>4</b>

## Release History

1.0.0	2014/09/26	1. Add documentation for ADAPTIVITY_VERSION 7.0, 7.1, 7.2
-------	------------	---

Realtek

## 1. Introduction

Realtek Wi-Fi solutions support both ETSI Adaptivity test and Carrier Sense test. This document describes ways to configure Wi-Fi driver for the corresponding test and simple debug methods.

※ According to the test requirement, the Wi-Fi performance will drop at interfering environment. Please enable this function only when you really need it.

## 2. Driver configuration

There are 2 configuration arguments in Makefile to control:

- **CONFIG\_RTW\_ADAPTIVITY\_EN**

- **disable**

- Disable adaptivity function

- **enable**

- Enable adaptivity function

- **CONFIG\_RTW\_ADAPTIVITY\_MODE**

- **normal**

- For ETSI adaptivity test

- **carrier\_sense**

- For carrier sense test

## 3. Driver configuration – disable (default setting)

To disable Realtek adaptivity function (also the default setting of these 2 configuration arguments):

```
CONFIG_RTW_ADAPTIVITY_EN = disable
CONFIG_RTW_ADAPTIVITY_MODE = normal
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
ADAPTIVITY_VERSION 7.2
RTW_ADAPTIVITY_EN_DISABLE
RTW_ADAPTIVITY_MODE_NORMAL
RTW_ADAPTIVITY_DML_DISABLE
TH_L2H_ini TH_EDCCA_HL_diff IGI_Base ForceEDCCAAdapEn_RSSI IGI_LowerBound
0xf5      7              0x32      0          20          0
```

#### 4. Driver configuration – enable for ETSI Adaptivity test

If your product needs to fit the requirement of ETSI Adaptivity test:

```
CONFIG_RTW_ADAPTIVITY_EN = enable  
CONFIG_RTW_ADAPTIVITY_MODE = normal
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity  
ADAPTIVITY_VERSION 7.1  
RTW_ADAPTIVITY_EN_ENABLE  
RTW_ADAPTIVITY_MODE_NORMAL  
RTW_ADAPTIVITY_DML_DISABLE  
TH_L2H_ini TH_EDCCA_HL_diff IGI_Base ForceEDCCAAdapEn_RSSI IGI_LowerBound  
0xf5      7      0x32      0      20      0
```

#### 5. Driver configuration – enable for Carrier Sense test

If your product needs to fit the requirement of Carrier Sense test:

```
CONFIG_RTW_ADAPTIVITY_EN = enable  
CONFIG_RTW_ADAPTIVITY_MODE = carrier_sense
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity  
ADAPTIVITY_VERSION 7.1  
RTW_ADAPTIVITY_EN_ENABLE  
RTW_ADAPTIVITY_MODE_CARRIER_SENSE  
RTW_ADAPTIVITY_DML_DISABLE  
TH_L2H_ini TH_EDCCA_HL_diff IGI_Base ForceEDCCAAdapEn_RSSI IGI_LowerBound  
0xf5      7      0x32      0      20      0
```